



3/8" dia  
SS bolt shaft  
axle / fender  
washers on each  
side of skeg

Allow a 1/16"+ free space on each side of the skeg once the washers are in. Skeg thickness varies as to what you can obtain. I used 3/16" Lucite. You can make it out of glass or plywood coated with fiberglass etc. My box is 1/4 birch plywood coated inside with glass. Install with a fillet and glass. Glass this assembly good since water is in it all the time.